

Maintenance and Care Instructions for MEGAL Cash Trays

Paint Coated Cash Tray:

- ✓ Clean with lukewarm water and typical cleaning agents.
- ✗ Avoid: scouring powders, wire brushes, or solvent-based agents.
- ✗ Improper cleaning products can damage the paint coating.

Stainless Steel Cash Tray:

- ✓ Clean with a soft, damp cloth and a mild cleaning liquid, then rinse with clean water (preferably demineralized to prevent water stains).
- ✓ Remove stubborn dirt using an organic solvent or unleaded gasoline.
- ✗ Avoid cleaners containing hydrochloric acid (HCl) – it damages the passive layer and leads to corrosion.